

Hahnemühle FineArt Inkjet Photo Cards







STEP 1 On a sheet of proofing paper (approx. 160gsm is best, at least A4 in size), print the template – this will be your template for the Photo Card.



STEP 2 In Photoshop, insert a 3mm bleed around the image (10 x 15 cm) that will be printed.



STEP 3 Line up a blank Photo Card on top of the template with a double sided tape. Use tape that is removable, and acid and softener-free.



STEP 4 Insert the template with the fixed Photo Card in the manual universal feeder of the printer and start printing. Your image should be lined up perfectly because of the template.

Technical support is available via phone: +49 (0) 5561791368 Find ICC Profiles: http://www.hahnemuehle.com/icc-profiles

Hahnemühle FineArt · dfa@hahnemuehle.com · www.hahnemuehle.com

